

665-ES MULTI-TASK ALL PURPOSE CLEANER

SPECIALTIES FOR MAINTENANCE AND SANITATION SINCE 1947

ENVIRONMENTALLY PREFERABLE CHEMISTRY



MULTI-TASK CLEANING MADE EASY!



COUNTER TOP

SAFE: No residue, fumes or harsh chemicals. No VOCs **CONVENIENT:** Ready to use, no mixing.

PROPELLANT FREE: Convenient aerosol like

pump dispensing.

VERSATILE: Porcelain, tile, plastic, chrome, stainless

steel, walls and counters.

EFFECTIVE: Removes dirt, grease, fingerprints and

oily grime.



LIGHT DEGREASING

ENTHUSIASTICALLY RECOMMENDED FOR:

- HOTELS
- GOV. AGENCIES
- VA HOSPITALS
- D.O.T.S.
- CITY, COUNTY, STATE ROAD DEPTS.
- COLLEGES
- SCHOOL SYSTEMS
- INSTITUTIONS
- VENDING



NET Wt. 12 FL. OZ.



TUBS, TILE & FIXTURES

Rev. 9-7-17

Toll Free: 800-238-5150 Local: 901-363-4340 Fax: 901-375-3600

Delta Foremost Chemical Corp.

3915 AIR PARK ST. • P.O. BOX 30310 • MEMPHIS, TENNESSEE 38130-310

Visit our Web Site at: www.deltaforemost.com

TECHNICAL DATA

FOREMOST 665-ES MULTI-TASK ALL-PURPOSE CLEANER

Rev. 9-7-17

DESCRIPTION:

Delta Foremost FM-665-ES Multi-Task All-Purpose Cleaner is a propellant-free spray that utilizes environmentally preferable chemistry to clean dirt, grease and oily grime from porcelain, ceramic tile, sealed granite, terrazzo, plastic, stainless steel, chrome, etc. Naturally, this all-purpose cleaner is made from biodegradable ingredients, was not tested on animals, and is in a recyclable container. Contains no harsh chemicals. Leaves no residue or fumes. Comfortable trigger spray.

APPLICATION:

An environmentally friendly composition with highly effective cleaning ability adapted to a variety of uses. Foremost 665-ES is recommended for cleaning dirt, grease and oily grime from appliances, counters and other hard surfaces in the kitchen, bathroom and other rooms. Use on porcelain, ceramic tile, sealed granite, terrazzo, plastic, stainless steel, chrome, etc. For painted surfaces, wall coverings or any surfaces about which you are unsure, test on a small inconspicuous area.

DIRECTIONS:

Hold can 8 to 10 inches away from the surface to be cleaned. PUMP THREE TO FOUR TIMES TO BEGIN SPRAYING. CONTINUE UNTIL THE SURFACE IS LIGHTLY MOISTENED. Wipe with a clean, dry paper towel or cloth. Do not spray directly on electronics, lamps, small appliances, etc. Spray cleaner onto a cloth and use that to wipe the surface.

PRECAUTIONS:

KEEP OUT OF REACH OF CHILDREN. May cause eye irritation. Avoid contact with eyes. Do not take internally.

FIRST AID: In case of contact, immediately flush eyes with large amounts of water until burning ceases. Get medical attention immediately if irritation persists.

Before using this product read the Safety Data Sheet (SDS) for more detailed information regarding safe handling.